

#73752, #73754, #73755 & #73759 Front Bulkhead for the Traxxas Slash 2wd, Nitro Slash, Stampede 2wd, Nitro Stampede, Bandit, Rustler & Nitro Rustler

Contents: 1 Front Bulkhead, 1 - Dust Plate & 1 - M3 x 6mm Flathead Screw. □

Assembly: The smooth, rounded side of the Dust Plate will orient towards the Bulkhead, with the dimples of the plate oriented towards the front of the Bulkhead. Slip the M3 x 6mm flathead screw through the Dust Plate and thread it into the Bulkhead using a 2mm hex driver (not included). Tighten until snug only. *Caution:* Do not over-tighten the screw!

Installation: Your new **RPM** Front Bulkhead is a stock replacement part. Simply remove your stock front bulkhead and replace it with the **RPM** version. □

